Starting Soon: Vapor Intrusion Mitigation Training — Session 1

Vapor Intrusion Mitigation Training Online Guidance Document, https://vim-1.itrcweb.org/.

Download PowerPoint slides

CLU-IN training page at https://clu-in.org/conf/itrc/VIM-1/. Under "Download Training Materials."

Use "Join Audio" option in lower left of Zoom webinar to listen to webinar Problems joining audio? Please call in manually

Dial In 301 715 8592

Webinar ID: 853 0438 9541#








Vapor Intrusion Mitigation

VIM-1, 2021

Session 1 (of 2)



Sponsored by: Interstate Technology & Regulatory Council (<u>www.itrcweb.org</u>) Hosted by: US EPA Clean Up Information Network (<u>www.clu-in.org</u>)



Housekeeping

Recording for On Demand Viewing



Course Information and Materials:

https://clu-in.org/conf/itrc/vim-1/



Technical difficulties? Use Q&A Pod



Certificate of Course Completion







ITRC

Disclaimer


https://vim-1.itrcweb.org/about-itrc/

Partially funded by the US government

ITRC nor US government warranty material

ITRC nor US government endorse specific products

ITRC materials available for your use – see Terms and Conditions









Today's Presenters



Susan McKinley
Indiana DEM
smckinle@idem.in.gov



David Folkes, P.E.Geosyntec
dfolkes@geosyntec.com



Emma Hong Luo, PhD
Chevron
Emma.hong.luo@chevron.com



Matthew WilliamsMichigan EGLE
williamsm13@michigan.gov



Eric Blodgett, P.E. Barr Engineering eblodgett@barr.com



Marek Ostrowski, P.E. Brown & Caldwell mostrowski@brwncald.com








Today's Training Topics



Conceptual Site Models for VI Mitigation

Rapid Response and Ventilation Outreach Materials



Source: Geosyntec & GSI Environmental, 2020. Used with permission

Public Outreach during VI Mitigation

Remediation and Institutional Controls as VIM Outreach Materials








Source: Barr Engineering, 2020. Used with permission.

What You Should Learn

- ▶ Background on the VIM Training team
- Overview of available documentation
- ► How access the mitigation strategies information
- ► Identify the sections that will be discussed in today's session





Not Covered in the VIM Training

- ► Emergency response actions Immediately contact first responders if
 - ► Reports of strong petroleum odors
 - ► Evidence of combustible, explosive, or oxygendeficient conditions inside the building
- ► Methane mitigation or hazardous substances that have a high explosive potential
- ► Radon



Figure from ITRC Petroleum Vapor Intrusion: Fundamentals of Screening, Investigation, and Management (2014).



Emerging Technologies Outreach Materials

Capture technologies and strategies that are not exclusively "mitigation" or "remediation"

- ► Aerobic Vapor Migration Barriers (AVMBs) create an aerobic biobarrier for petroleum vapors
- ▶ Placeholder for inclusion of emerging technologies in the future






Figure 1 from the AVMB Technology Information Sheet.



Vapor Intrusion Mitigation (VIM) Training Team Background

- ► Previous ITRC guidance documents focused on investigative process
- ► Multiple requests for "...additional details and training on mitigation"





https://www.itrcweb.org/Documents/VI-1.pdf https://www.itrcweb.org/PetroleumVI-Guidance/







What is Vapor Intrusion (VI)

- Contaminants in soil and groundwater can volatilize into soil gas
- ► VI occurs when these vapors migrate upward into overlying buildings and contaminate indoor air
- ► If present at sufficiently high concentrations:
 - ► These vapors may present a threat to the health and safety of building occupants



Source: ITRC Petroleum Vapor Intrusion Guidance (PVI-1, 2014)





Different Types of Vapor Intrusion

► Chlorinated Vapor Intrusion (CVI) which addresses chlorinated compounds

► Petroleum Vapor Intrusion (PVI) is a subset of VI that deals exclusively with petroleum hydrocarbon (PHC) contaminants



Source: ITRC Vapor Intrusion Pathway: A Practical Guideline (VI-1, 2007)




Source: ITRC Petroleum Vapor Intrusion Guidance (PVI-1, 2014)





VI Mitigation (VIM)


- ► Implemented to reduce indoor air contaminants due to VI below applicable action or screening levels
- Accomplished by
 - ► Modifying the VI pathway to reduce the mass flux of contaminants entering the building
 - ► Reducing indoor air contaminant concentrations by removal or dilution





What is VI Mitigation (or Vapor Control)?

- ► VOC Vapor control can include
 - ► Source remediation
 - ► Active or passive mitigation
 - ► Rapid response
 - ► Institutional controls



Source: Geosyntec & GSI Environmental, 2020. Used with permission.







Steps in the VIM Process

Pre-System Installation

- 1. Assessment of Site Conditions
- 2. Technology Selection
- 3. Develop and Document System Design

System Installation

- 4. Pre-construction Meeting
- 5. Installation
- 6. Installation Oversight

Post-System Installation


- 7. System Verification
 - a) Inspection
 - b) Verification Sampling
 - c) Confirming Performance QA/QC
- 8. Documentation
- Operation, Maintenance, and Monitoring





ITRC VIM Webpage

- ► Interactive Directory
- ► Fact Sheets
- ► Technology Information Sheets
- ► Flow Chart for VIM CSM Development (Figure 2-1)
- ► Considerations and impacts of various VIM approaches
- ▶ Checklists
- ▶ Additional information




https://vim-1.itrcweb.org/







Process Fact Sheet Rating System



Medium impact •

High impact

Kev |








Not applicable —

Process Fact Sheet Narrative



Design consideration	Active approaches	Passive approaches	Remediation	Rapid response
VI CSM considerations				
Vapor source and concentration				
Vapor source and concentration	•	•		•
Geology and hydrogeology				
Subgrade soil type	•	-	•	<u>-</u>
Depth to groundwater/high water conditions	•	•	•	•

Key High impact ● Medium impact ● Le	Low impact ☐ Not applicable —
--	---------------------------------

Subgrade Soil Type: In most cases, the properties of soils immediately adjacent to the building (e.g., below the slab or next to foundation walls and footings) have the greatest impact on active mitigation technologies that require the movement of air and/or the propagation of vacuum below the slab. Soil type plays a major consideration for active mitigation strategies and makes some remediation technologies difficult to implement. For a more detailed description of methods to test and mathematically model the sub-slab permeability and transmissivity see (McAlary et al,, 2018 ▷). See Section J.2.5 of Appendix J in the 2014 ITRC PVI document (ITRC, 2014 ▷) for more information on the consideration of soil type in active mitigation.


Active Mitigation	High Impact: Permeability of the sub-slab fill material and underlying soil controls the pressure field extension (PFE) and air flow rates and, therefore, the degree to which sub-slab depressurization (SSD) and sub-slab ventilation (SSV) contribute to indoor air quality protection. This affects the spacing of suction points and fan size required to induce and maintain the negative pressure field beneath the structure.
Passive Mitigation	Low Impact: Passive mitigation systems typically incorporate a permeable layer beneath barriers and around vent piping in new construction. It may not be feasible to incorporate a permeable layer beneath an existing building. Therefore, passive venting systems function best in soils that are highly permeable when retrofitting an existing building.
Environmental Remediation Technology	High Impact: Remediation technologies require the characterization of soils beyond the subsurface to evaluate the effectiveness of the proposed technology. MPE and SVE are generally not applicable to low-permeability soils.
Rapid Response	Low Impact: Rapid responses typically include <u>ventilation</u> changes, indoor air treatment, or other efforts that are focused inside the building, therefore sub-slab conditions are not relevant.







Checklists










Coming Up Next...












Conceptual Site Models for Vapor Intrusion Mitigation



Source: Geosyntec & GSI Environmental, 2020. Used with permission.



Objectives of Module

- ► Understand the importance of a VI "mitigation CSM"
- ► Identify data needed to enhance the CSM
- ▶ Use the enhanced CSM to evaluate mitigation options








What is a Mitigation CSM?

- ► The VI CSM describes the VI pathway
- ► Mitigation modifies the VI pathway to reduce potential exposure
- ► A "mitigation-grade" CSM has sufficient information to evaluate mitigation alternatives



Source: Geosyntec & GSI Environmental, 2020. Used with permission.








How can we modify or control the VI Pathway?

- ► VOC Vapor control can include
 - ► Source remediation
 - ► Active or passive mitigation
 - ► Rapid response
 - ► Institutional controls



Source: Geosyntec & GSI Environmental, 2020. Used with permission.








Example of additional information needed to evaluate mitigation options

Evaluation of active/passive mitigation options may require additional information concerning:


- Sub-slab VOC concentrations
- Sub-slab soil and moisture conditions
- ► Slab integrity
- ▶ Building features that block or shortcircuit sub-slab air flow





Preferential Pathway Considerations

- ► The CSM should consider the potential for sewer/pipe preferential pathways
- ► Pathways that connect vapor sources to the building can dominate VI
- ► Mitigation options must control these pathways (potentially in addition to other pathways)



Source: Geosyntec & GSI Environmental, 2020. Used with permission.



Large buildings may have multiple Mitigation CSMs


Example of building with multiple sources, variable pathways, and variable building conditions

Original Building

Legend

Advective-controlled pathway

Diffusion-controlled pathway










Large buildings may have multiple VI pathways

Multiple Mitigation CSMs may require multiple vapor control strategies



Legend



Rapid Response

Active/Passive

Remediation/ICs



Knowledge Check

What is a component of the Mitigation CSM?

- Contaminant type
- ▶ Distance between VOC source and building
- ► Location and depth of sanitary sewers
- ► Condition of building slab
- ► All of the above
- ▶ None of the above



Image source: Pixabay



Knowledge Check

What is a component of the Mitigation CSM?

- Contaminant type
- ▶ Distance between VOC source and building
- ► Location and depth of sanitary sewers
- ► Condition of building slab
- ☑ All of the above
- ▶ None of the above







CSM for VI Mitigation Flow Chart

d---

5 ---

☐ Crack Advection /

Concrete Diffusion

n ••••

(Vapor) Sewers /

Conduits Sumps / Vaults

13

Volatilization / Soil

Vapor Migration

Groundwater

Transport

Crack Advection /

Concrete Diffusion








Figure 2-1 of the ITRC CSM Fact Sheet

Controls / Caps / Ventilation

(s, t) [above slab] vapor barriers, crack sealing, false walls / plenums; (q, r) (sump) covers, plumbing traps, pumping seals, etc.

Sub-Slab Vapor Controls

(n, o, p) [below slab] vapor barriers, sub-slab depressurization, sub-slab ventilation, etc.

Remediation

Vapor Extraction / Removal

(k, l, m) soil vapor extraction, biodegradation bioventing, etc.

(Liquid) Boundary Containment

(h, i, j) hydraulic containment, slurry walls, sheet pile, reactive boundary, etc.







CSM for VI Mitigation Checklist

- Supports a systematic site evaluation
- Helps verify understanding of important details
- ► Facilitates data gaps identification

Excerpt of "Building" Section of CSM Checklist

5. Buildings

Locate and map out existing buildings, identify square footage, and identify areas for potential future construction if known. If multiple buildings are being evaluated, tabulation of the following for each building may be necessary. Also, building additions may need to be evaluated separately. Note that a detailed, building-specific evaluation may not be needed if the VI mitigation effort is focused on the COC source area or pathway outside of the building envelope. In the descriptions below, include references to site reports, as necessary, to support the discussion. Attachments to this checklist with, for example, copies of figures may also be provided.

5.1 Structure

- · Indicate current building use:
- □ Residential
- □ Non-Residential

If non-residential, could future use include residential? ☐ Yes ☐ No

□ Unknown

Are land use controls (LUCs), use restrictions, institutional controls, or equivalent in place? ☐ Yes ☐ No

Note: If current or future site use is or could be residential, the most conservative state and federal regulations apply for technology selection and design.

- Indicate structure status:
- □ Existing construction
- □ New construction
- □ Potential future construction

https://vim-1.itrcweb.org/vapor-intrusion-mitigation-conceptual-site-model-checklist/

Knowledge Check

When is it important to verify and update the Mitigation CSM?

- ▶ During mitigation design and planning
- ► At the time of mitigation implementation
- ► During long-term management
- ► All of the above
- ▶ Never







Knowledge Check


When is it important to verify and update the Mitigation CSM?

- ▶ During mitigation design and planning
- ► At the time of mitigation implementation
- ► During long-term management
- ☑ All of the above
- ▶ Never






Additional CSM Resources



ITRC VI Pathway Guidance (2007)
https://www.itrcweb.org/Documents
/VI-1.pdf



ITRC Petroleum VI Guidance (2014) Appendix D (PVI CSM Checklist)

https://www.itrcweb.org/ PetroleumVI-Guidance/



Fact sheet – Conceptual Site Models for Vapor Intrusion Mitigation (2020)

https://vim-1.itrcweb.org/conceptual-site-modelsfor-vapor-intrusion-mitigation-fact-sheet/







Summary

- ► VI CSM evolves throughout the life of a project
- ▶ "Mitigation CSM" helps to
 - ► Identify information needed to evaluate mitigation options
 - ► Support Public Outreach




Source: Geosyntec & GSI Environmental, 2020. Used with permission.





Coming Up Next...











Public Outreach During Vapor Intrusion Mitigation (VIM)






Objectives of Module

Understand public outreach for VI mitigation:

- ▶ differs from other environmental matters
- ► continues through long-term management
- ▶ is diverse, iterative and everyone's job







Public Outreach During Vapor Intrusion

- ▶ VI work takes place indoors
- ► Topic is unfamiliar to the public
- ▶ It's about the air we breathe
- Mitigation involves modifications to a building





Key Components of Public Outreach for VI

- ► Consider outreach early and often
- ▶ Be transparent
- ► Maintain relationships
- Recruit partners (e.g., translators, community organizers)
- ▶ Listen

Hi, we're here to install a vapor intrusion mitigation system.










Communicating Vapor Intrusion is Complicated



- ▶ Unfamiliar words
- Numerous things to measure and compare
- ► Variability of results
- ▶ Background contributions from common consumer products







Communicating Vapor Intrusion Mitigation is Also Complicated

- ► Use analogies (e.g., radon mitigation)
- ► Address questions and concerns
- ▶ Rely on intermediaries/partners as needed







Questions from the Public









Multiple Communication Tools Needed

- Repeated conversations with same party
- ► Emphasize that mitigation protects building occupants
- ► Communicate by multiple methods
 - ► Group setting
 - ► Fact sheets
 - ▶ Social media
 - ▶ One-on-one discussions




Source: Pixabay (adapted)





Communication is Everyone's Job

- Every interaction and perception matters
- Every stakeholder plays a role in communication
- ▶ Be mindful of situations where the occupant is not the owner







Communication on Long-Term Management

- ► Long-term management is a key part of mitigation success
- ▶ Need a plan for communicating:
 - System issues
 - ► Remodeling work
 - ► Institutional/engineering controls at property transfer
- Provide labeling, contact information, and essential documentation
 - ► Retain a copy if lost or misplaced

Labeling and contact information

Essential Documentation



Source: L. Levy, 2020. Used with permission.







Knowledge Check

When is it important to do public outreach?

- During VI investigation
- ▶ During mitigation design and planning
- ► At the time of mitigation implementation
- ► During long-term management
- ► All the above



Image source: Pixabay



Knowledge Check


When is it important to do public outreach?

- During VI investigation
- ▶ During mitigation design and planning
- ► At the time of mitigation implementation
- ► During long-term management
- ☑ All the above






Additional Resources




Fact sheet – Public Outreach During Vapor Intrusion Mitigation (2020)

https://vim-1.itrcweb.org/public-outreachduring-vapor-intrusion-mitigation/



ITRC Petroleum VI Guidance (2014)
Section 7 Community Engagement
https://www.itrcweb.org/

PetroleumVI-Guidance/



ITRC Risk Communication Toolkit (2020) https://rct-1.itrcweb.org/







Question & Answer Break



Source: Pixabay








Advancing Environmental Solutions


Rapid Response for Vapor Intrusion Mitigation





Objectives of Module

- ► Definition of rapid response for vapor intrusion mitigation
- Overview
- ▶ When to implement
- ► Administrative and engineering controls for rapid responses





What is Rapid Response?

- Mitigation implemented within days or weeks of vapor intrusion discovery
- ► Addresses acute public health risk
- ► Interim response action
- ► May be different from final response
 - ► Limited design effort
 - ▶ Different verification testing considerations
 - ► Limited OM&M

Other Terms for Rapid Response

imminent hazard response urgent response

emergency response expedited response

immediate response accelerated response





What is not covered in these presentations

- ► Emergency response actions Immediately contact first responders if
 - ► Reports of strong petroleum odors
 - ► Evidence of combustible, explosive, or oxygendeficient conditions inside the building
- ► Methane mitigation or hazardous substances that have a high explosive potential
- ► Radon



Source: ITRC Petroleum VI Guidance (2014)



Knowledge Check

Which of these scenarios could warrant a rapid response?

- A. Petroleum vapor intrusion has been documented in a vacant gas station
- B. High levels of TCE have been detected in sub-slab soil gas at maternity clinic
- C. TCE levels have been detected slightly above state vapor intrusion action levels at an occupied commercial building
- D. Benzene has been detected at high levels in soil gas at a vacant lot planned for redevelopment



Image source: Pixabay





Knowledge Check

Which of these scenarios could warrant a rapid response?

- A. Petroleum vapor intrusion has been documented in a vacant gas station
- B. High levels of TCE have been detected in sub-slab soil gas at maternity clinic
- C. TCE levels have been detected slightly above state vapor intrusion action levels at an occupied commercial building
- D. Benzene has been detected at high levels in soil gas at a vacant lot planned for redevelopment



Source: Pixabay





Rapid Response & Ventilation Fact and Tech Sheets

- ▶ Defines what is a rapid response and when to implement
- ► Lists administrative and engineering controls for rapid responses

Vapor Intrusion Mitigation (VIM)

номе

Rapid Response & Ventilation for Vapor Intrusion Mitigation Fact Sheet

ITRC has developed a series of fact sheets that summarizes the latest science, engineering, and technologies regarding wappr-intrusion (VI) mitigation. The fact sheets are tailored to the needs of state regulatory program personnel who are tasked with making informed and timely decisions regarding VI-impacted sites. The content is also useful to consultants and parties responsible for the release of these contaminants, as well as public and tribal stakeholders. This fact sheet:

- · provides an overview of rapid response as a preliminary method to consider
- describes the typical options related to rapid response
- describes the advantages and limitations of implementing a rapid response
- provides general cost considerations related to rapid response
- · describes other special circumstances to consider when deciding if rapid response is applicable

More detailed information on specific rapid response options is included in the ITRC <u>Preferential Pathway Sealing and Ad</u> <u>Hoc Ventilation</u>, <u>Indoor Air Treatment</u>, and <u>HVAC Modification Technology Information Sheets</u>.

1 Introduction

Rapid response is an interim VI mitigation approach that may be appropriate, under certain conditions (e.g., high contaminant concentrations and sensitive populations present), prior to implementing a long-term mitigation strategy for an occupied room or building. For the purposes of this fact sheet, a rapid response is one that could be easily implemented and verified on a timescale of days to weeks, whereas a long-term mitigation strategy typically

Other Terminology Used to Describe a Rapid Response

 Depending on the regulatory framework and the measured indoor or subsurface concentrations for the chemical(s) of concern, the term "rapid response" can correspond to one or more of the following:

https://vim-1.itrcweb.org/rapid-response-ventilation-for-vapor-intrusion-mitigation-fact-sheet/








Rapid Response Focused on Structure and Occupants

- **▶** Building occupants
- ► Preferential pathways
- Building pressure
- ► Air exchange rate








Categories of Rapid Response Administrative Controls

- ▶ Notification
- ▶ Relocation










Categories of Rapid Response **Engineering Controls**

- Preferential pathway sealing
- ▶ Ad hoc ventilation










Categories of Rapid Response **Engineering Controls**

- Preferential pathway sealing
- ► Ad hoc ventilation
- ► Indoor air treatment










Categories of Rapid Response Engineering Controls


- Preferential pathway sealing
- ▶ Ad hoc ventilation
- ► Indoor air treatment
- **►** HVAC modification









Rapid Response & Ventilation Technology Information Sheets



Preferential Pathway Sealing and Ad Hoc Ventilation



Indoor Air Treatment



HVAC Modification







Poll

Which of these administrative and engineering controls have you implemented or seen implemented? (Check all that apply)

- A. Notification
- B. Relocation
- C. Preferential Pathway Sealing and Ad Hoc Ventilation
- D. Indoor Air Treatment
- E. HVAC Modification



Source: Clipartmax.com






Tech Sheet – Preferential Pathway Sealing

Overview

- ► Advection vs. Diffusion
- Preferential pathway sealing blocks advection
 - ► Benefits long-term mitigation



https://vim-1.itrcweb.org/preferential-pathway-sealing-ad-hoc-ventilation-tech-sheet/






Tech Sheet – Ad Hoc Ventilation

Overview

- ► Ad hoc ventilation = dilution
 - ► Weather dependent



https://vim-1.itrcweb.org/preferential-pathway-sealing-ad-hoc-ventilation-tech-sheet/







Preferential Pathway Sealing Components



Source: Sanborn, Head & Associates, Inc.

Vent through roof
Vapors
Liquid seal in P-Trap blocks vapors from entering

Trap seal (water or vegetable oil)

Source: Barr Engineering Co.



Source: Barr Engineering Co.

ant applied
Add water to dry drain










Tech Sheet – Indoor Air Treatment Overview

- ► Implemented via air purifying units (APUs)
- ▶ Treats air inside building
- ► Subject to human interference



Source: Barr Engineering, 2020. Used with permission.


https://vim-1.itrcweb.org/indoor-air-treatment-tech-sheet/







Tech Sheet – Indoor Air Treatment Components



Example adsorption-based APU

Source: Sanborn, Head & Associates, 2021. Used with permission.



Photograph from Figure 1 of the Indoor Air Treatment Technology Information Sheet.








Tech Sheet – HVAC Modification Overview

- ► Increase air exchange rate
- ► Increase building pressure
- Most suitable for commercial/industrial buildings
- Can supplement other mitigation methods




https://vim-1.itrcweb.org/heating-ventilation-and-air-conditioning-hvac-modification-tech-sheet/





Tech Sheet – HVAC Modification Components

Fresh outside air enters the HVAC unit through dampers and is distributed via a supply fan



https://vim-1.itrcweb.org/heating-ventilation-and-air-conditioning-hvac-modification-tech-sheet/






Source: Sanborn, Head & Associates, 2020. Used with permission.

Tech Sheet – HVAC Modification Components

Indoor air is collected by the return air fan and is reused as makeup air, or discharged from the building



https://vim-1.itrcweb.org/heating-ventilation-and-air-conditioning-hvac-modification-tech-sheet/






Source: Sanborn, Head & Associates, 2020. Used with permission.

Tech Sheet – HVAC Modification Components

Some indoor air is directly exhausted from the building via exhaust fans



https://vim-1.itrcweb.org/heating-ventilation-and-air-conditioning-hvac-modification-tech-sheet/








Source: Sanborn, Head & Associates, 2020. Used with permission.

Coming Up Next...












Environmental Remediation & Institutional Controls



Source: Geosyntec & GSI Environmental, 2020. Used with permission.

Objectives of Module

- ► Difference between remediation and mitigation
- ▶ Description of two soil vapor remediation methods that address vapor intrusion (VI)
- ▶ Introduction to institutional controls (IC)






Remediation vs. Mitigation

REMEDIATION

- Reduce mass in the source medium: soil, groundwater, or free phase
- Site-wide
- Longer-term installation, i.e., months



Source: Shell Global Solutions (US) Inc.
Used with permission.

MITIGATION


- ► Limit or prevent exposure at some point along the VI pathway
- Building-specific
- Shorter-term installation, i.e., weeks
- May also provide a remediation benefit





Remediation as Mitigation Remediation Technologies for the Vadose Zone

- ► Targeted COCs: Hydrocarbon and chlorinated solvent vapors
 - ► Gas/vapor in the vadose zone, and exposure pathway drive the human health risk
 - ▶ Mitigation addresses the pathway, remediation can address both
 - ▶ Applicable remediation technologies: SVE and MPE



See SVE and MPE Tech Sheets.

https://vim-1.itrcweb.org/soil-vaporextraction-sve-tech-sheet/

https://vim-1.itrcweb.org/multiphaseextraction-mpe-tech-sheet/



Tech Sheet – Soil Vapor Extraction (SVE)




Figure 1 from the ITRC SVE Technology Information Sheet

- ► Targets only the vadose zone
- ► Intercepts soil vapors
- Creates sub-surface pressure gradient away from the building slab
- Performance typically evaluated based on current/planned site use

https://vim-1.itrcweb.org/soil-vaporextraction-sve-tech-sheet/







Tech Sheet – Multi-phase Extraction (MPE)




Figure 1 from the ITRC MPE Technology Information Sheet

- ► Targets vadose zone *and* saturated zone
- ► Intercepts soil vapors and withdraws water/free product (if present)
- Performance not linked to vadose zone thickness

https://vim-1.itrcweb.org/multiphaseextraction-mpe-tech-sheet/







Poll

Have you been involved with a site that has a deed restriction or land use control as part of VI mitigation strategy; if so, which? (check all that apply)

- A. Construction requirements
- B. Building type
- C.Occupancy
- D.Required active or passive vapor mitigation
- E. Restrictions on groundwater use
- F. Other



Source: Clipartmax.com





Tech Sheet – Institutional Controls (IC)



Source: ITRC Long Term Contaminant Management Using Institutional Controls Guidance

https://vim-1.itrcweb.org/institutional-controls-ic-tech-sheet/

Long-term measures that provide:

Protection from exposure to contaminants

Assurance that VI mitigation system will be maintained

Applied alone or in combination with other remedies

Government controls: Zoning ordinances, groundwater use or drilling limitations, land development regulations, etc.

Proprietary controls: Private agreement between landowner and outside party that "run with the land"

Enforcement mechanisms: Government agency-issued permits, administrative orders, etc.

Informational devices: Provide information about risks from site COCs







Knowledge Check

When might you consider implementing ICs?

- A. Remediated site that includes a passive venting system
- B. Remediated site that includes an active venting system
- c. Potential future land development
- D. All of the above
- E. None of the above



Source: Pixabay



Knowledge Check


When might you consider implementing ICs?


- A. Remediated site that includes a passive venting system
- B. Remediated site that includes an active venting system
- c. Potential future land development
- ✓ All of the above
- E. None of the above





Additional ITRC Resources





"DNAPL Source Reduction: Facing the Challenge" (DNAPLs-2, 2002)

"Enhanced Attenuation: Chlorinated Organics" (EACO-1, 2008)

"Enhanced In-Situ Bioremediation of Chlorinated Solvents in Groundwater" (ISB-6, 1998)

"In-Situ Chemical Oxidation of Contaminated Soil & Groundwater" (ISCO-2, 2005)

"Evaluating LNAPL Remedial Technologies for Achieving Project Goals" (LNAPL-2, 2009)

"Long Term Management Using Institutional Controls" (IC-1, 2016)





Thank you for attending!

Email further questions on today's session to:

itrc@itrcweb.org

Feedback Form & Certificate of Completion:

https://clu-in.org/conf/itrc/VIM-1/feedback.cfm

Vapor Intrusion Mitigation Training:

https://clu-in.org/conf/itrc/vim-1

Questions



