

Case Studies of Advances in Bioremediation of Organics: Part 1

May 29, 2020

Anthony Danko, Ph.D., P.E.
Environmental Engineer
NAVFAC EXWC

Disclaimer



- **This seminar is intended to be informational and does not indicate endorsement of a particular product(s) or technology by the Department of Defense or NAVFAC EXWC, nor should the presentation be construed as reflecting the official policy or position of any of those Agencies.**
- **Mention of specific product names, vendors or source of information, trademarks, or manufacturers is for informational purposes only and does not constitute an endorsement or recommendation by the Department of Defense or NAVFAC EXWC. Although every attempt is made to provide reliable and accurate information, there is no warranty or representation as to the accuracy, adequacy, efficiency, or applicability of any product or technology discussed or mentioned during the seminar, including the suitability of any product or technology for a particular purpose.**
- **Participation is voluntary and cannot be misconstrued as a new scope or growth of an existing scope under any contracts or task orders under NAVFAC.**

Outline



- **Chlorinated Solvents**

- Molecular Tools
- Electrokinetic Bioremediation


- **1,4-Dioxane**

- ^{14}C Assay
- Aerobic Cometabolism using Multiple Primary Substrates


Case Study – qPCR and 16S Sequencing at NAS JAX

Site Background

- Operable Unit 3 (OU3) occupies 134 acres on eastern side of installation
- Industrial/commercial land use
- Fleet Readiness Command (FRC) (formerly NADEP) primary tenant on installation since 1940s
- Former dry cleaner facility located within OU3 property
- 7 identified groundwater plumes (Areas A – G)
- Buildings 780 and 106 also sources of contamination



Case Study – qPCR and 16S Sequencing at NAS JAX Enhanced *In Situ* Bioremediation Application




Legend

- ◆ Temporary DPT Location
- ◆ Existing Sand Well
- Target Treatment Area (TTA)
- ◆ Existing Soil Gas Probe
- ◆ Existing Sand/Clay Well



- 50 DPT injection locations
- 2 injection intervals per location
- 145,000 gallons of an 0.7% emulsified vegetable oil solution (EDS-ERTM)
- Average flow rate of 1.8 gpm
- 100 liters of KB-1® and KB-1® Plus injected
- Bromide tracer used
- 10 performance monitoring wells
- 4 soil gas probes

Case Study – qPCR & 16S Sequencing at NAS JAX CVOC Results



Legend

- Performance Monitoring Well
- Soil Gas Probe
- UIC Monitoring Well
- Temporary DPT Injection Location
- Target Treatment Area (TTA)




• Anticipate • Innovate • Accelerate •

Case Study – CVOC qPCR & 16S Sequencing at NAS JAX


Microbial Composition



Upgradient Well MW-40S



Pilot Test Well PZ-02




Bacteria	% of Bacteria	
	MW-40S	PZ-02
<i>Dehalococcoides</i>	0.01%	5%
<i>Geobacter</i>	0.09%	24%
<i>Methylobacter</i>	9%	9%

• Anticipate • Innovate • Accelerate •

Electrokinetic (Ek) Bioremediation




- Low permeability silts and clays ($K < 10^{-7}$ m/s) present challenge for amendment distribution
- This technology leverages the electrical properties of the amendments to promote distribution
- Technology applies an electric current to facilitates electromigration and electro-osmosis
- Successfully demonstrated in Denmark to treat PCE
 - Generated lactate flow of 3 to 5 cm/day through clay



Ek-Bio Demonstration at NAS Jacksonville, FL (ESTCP ER-201325)





- Potassium lactate and KB-1 (2 Stages)
- Stage 1
 - 100 gallons, 60% lactate
 - 4 L KB-1 into each of 8 supply wells & 2 L KB-1 into each of 9 electrode wells
 - Introduced over 6 months



Ek-Bio Demonstration at NAS Jacksonville, FL (ESTCP ER-201325)




Results (cont¹)



PCE at
15 – 40 mg/L
in clay






Ek-Bio Demonstration at NAS Jacksonville, FL (ESTCP ER-201325)

Results (c



Electrode Wells in **RED**

Monitoring Well in **Grey**



Outline




- **Chlorinated Solvents**
 - Molecular Tools
 - Electrokinetic Bioremediation
- **1,4-Dioxane**
 - ^{14}C Assay
 - Aerobic Cometabolism using Multiple Primary Substrates

1,4-Dioxane – ESTCP 201730



- Many 1,4-dioxane plumes appear to attenuate; how to prove?
- Multiple lines of evidence approach, including:
 - Concentration trend analysis; plume mass estimates; CSIA; biomarkers
- More direct evidence of aerobic biodegradation may be needed
 - Challenge: Aerobic biodegradation of 1,4-dioxane yields CO₂, biomass, and possibly soluble intermediates; *how to document product formation?*
- ¹⁴C assays quantify products and allow for measurement of a rate coefficient



n = 103 sites where dioxane and chlorinated solvents co-occur

Adamson et al., 2014

What is BioPIC (ESTCP ER-201129)?



- **Bioremediation Pathway Identification Criteria**
- Updated protocol for evaluating natural attenuation
- Guides users in the selection of MNA, biostimulation and/or bioaugmentation or other remedial technology
- Spreadsheet driven (Excel™)
- Currently limited to chlorinated ethenes
 - Development of 'BioPic 2.0' for 1,4-Dioxane and associated cVOCs (ESTCP 201730)



United States
Environmental Protection
Agency

Office of Research and
Development
Washington DC 20460

EPA/600/R-98/128
September 1998

Technical Protocol for Evaluating Natural Attenuation of Chlorinated Solvents in Ground Water



Based on EPA/600/R-98/128 (Sep 1998)


To Obtain BioPIC

Search under ER-201129 Report at SERDP-ESTCP

• Anticipate • Innovate • Accelerate •

1,4-Dioxane – ESTCP 201730

GOAL: *Develop tool that will walk RPMs through this process for evaluating MNA*



1,4-Dioxane – ESTCP 201730



- Geographic diversity
 - ≥ 4 states; East coast, West coast, Midwest
- Mix of Department of Defense and industrial sites (7 sites)
- All exhibit a decrease in C/C_0 along plume axis
 - Range of 1,4-dioxane concentrations: 163-11,000 $\mu\text{g/L}$; median = 169 $\mu\text{g/L}$
 - Range of VOC co-contaminant concentrations: non-detect to 6 mg/L; 1,1-DCE from non-detect to 162 $\mu\text{g/L}$
- 3-5 wells sampled per site; repeat samples for 2 sites
- Monitored: $\Delta^{14}\text{C}$ products; Δ 1,4-dioxane; VOCs; ΔO_2
 - Also included CSIA and relevant biomarkers

Basic Test Procedure: ^{14}C Assay

Collect GW samples:
Triplicate serum bottles + 2 L

↓
Ship overnight on ice

↓
Warm overnight to
room temperature

↓
Prepare triplicate filter
sterilized GW controls
from 2 L sample

→ Add purified ^{14}C -1,4-dioxane

↓
Measure initial conditions:
 ^{14}C , 1,4-DX, VOCs, O_2


↓
Sample weekly (5 mL)
for 6 weeks:
measure ^{14}C products

→ Calculate $k_{\text{net}} =$


$k_{\text{GW}} - k_{\text{FSGW}}$
and net 95% Confidence Interval

↓
End of incubation
analyses:
 ^{14}C products, 1,4-DX, VOCs, O_2

1,4-Dioxane – ESTCP 201730




1,4-Dioxane – ESTCP 201730



Overall

- 36 well samples analyzed
- 12 have statistically significant rate coefficients
- Maximum rate coefficient* = 0.096 yr^{-1}
 Median rate coefficient = 0.0061 yr^{-1}

1,4-Dioxane – ESTCP 201730



- Highest rate constants at the lowest VOCs and 1,1-DCE
- Rate constants found at
 - 6.3 μM VOCs
 - 29 μg/L 1,1-DCE (0.30 μM)
- VOCs likely slow in situ rates

1,4-Dioxane – ESTCP 201733


Multiple Primary Substrates: Isobutane + Methane

Process A: Isobutane + Oxygen

- Stimulate Isobutane degraders
- 1,4-D targeted
- 1,1-DCE and select other CVOCs

Process B: Methane + Oxygen


- Stimulate methanotrophs
- TCE targeted
- Select other CVOCs



1,4-Dioxane – ESTCP 201733




NAS North Island: Operable Unit 11




1. Waste disposal–surface impoundments
2. Shallow aquifer (25'-40' BGS)
3. Neutral pH
4. Comingled 1,4-D and CVOCs (mg/L)

1,4-D Plume





TCE Plume



• Anticipate • Innovate • Accelerate •

1,4-Dioxane – ESTCP 201733

- Sandy Aquifer: 25' - 40' bgs
- Low permeability unit at 40'



1,4-Dioxane – ESTCP 201733

Discrete groundwater sampling results

- Concentrations generally increasing with depth
- Plume located from ~30' to 40' bgs

Boring ID	HPT-1			HPT-2			HPT-3		
Depth (ft, bgs)	29	34	39	27.5-29	32.5-34	38-39.5	25.5-28	32-33.5	38-39.5
Compound/Concentration	µg/L	µg/L	µg/L	µg/L	µg/L	µg/L	µg/L	µg/L	µg/L
TCE	<5	155	1360	<5	323	851	7	210	2108
1,1-DCE	<5	135	1168	<5	311	667	15	339	2140
1,4-Dioxane	0.94J	69.8	427	234	107	240	50.2	415	1107
cis-1,2-DCE	<5	72	328	<5	100	89	30	293	613
1,1-DCA	<5	13	136	<5	34	58	<5	34	198
Vinyl Chloride	<5	<5	6	<5	<5	<5	<5	<5	15
Chloroform	<5	<5	5	2J	1J	3J	<5	2J	7
1,2-DCA	<5	<5	<5	<5	<5	<5	<5	1J	6
PCE	<5	<5	4J	<5	<5	<5	<5	<5	6
trans, 1,2-DCE	<5	<5	3J	<5	<5	<5	<5	<5	3J
1,1,2-TCA	<5	<5	<5	<5	<5	<5	<5	<5	1J


1,4-Dioxane – ESTCP 201733




Microcosm Test

Objectives

1. Can indigenous organisms be stimulated to degrade 1,4-D and target cVOCs?
 - Evaluating several alkane/alkene gases
2. Are low levels achievable?
3. Nutrients required/beneficial?
4. Bioaugmentation required?




1,4-Dioxane – ESTCP 201733




Isobutane Treatments

- No isobutane uptake in 107 days
- Suspect 1,1-DCE toxicity
- ENV493 added on day 107
- Rapid transformation of 1,1-DCE
- Uptake of isobutane (3 days)



• Anticipate • Innc


1,4-Dioxane – ESTCP 201733



Isobutane Treatments

- ENV493 added on day 107
- 3 successive spikes of isobutane
- Rapid transformation of 1,4-dioxane, *cis*-DCE and chloroform


1,4-Dioxane – ESTCP 201733



Isobutane Treatments

- Limited cometabolism of TCE by ENV493
- Mixed methanotroph culture ENV494M and methane added
- TCE degraded and methane uptake observed

1,4-Dioxane – ESTCP 201733




Both Cultures
Isolated from the Site

1,4-Dioxane – ESTCP 201733



Preliminary MODFLOW Modeling Simulation



Groundwater Modeling

- Groundwater recirculation
 - 1 extraction well
 - 5 injection wells
 - 15' well spacing
- ~8-10 gpm – 8 hr/day
- Substrate gas & nutrient addition
- Bioaugmentation

Acknowledgements



- **ESTCP ER-201325 (Geosyntec, USACE, NAVFAC SE)**
- **ESTCP ER-201730 (NAVFAC EXWC, GSI, Clemson Univ., Scissortail, Independent Consultant)**
- **ESTCP ER-201733 (NAVFAC EXWC, APTIM, Oregon St. Univ., NC St. Univ.)**
- **NAVFAC SE and SW**



Thank you!