

Starting Soon: Hydrocarbons 101 Training

This event is being recorded; Event will be available On Demand after the event at the main training page


<https://www.clu-in.org/conf/itrc/Hydrocarbons/>

- If you have technical difficulties, please use the Q&A Pod to request technical support

Need confirmation of your participation today?

- Fill out the online feedback form and check box for confirmation email and certificate

ITRC: Introduction to Hydrocarbons



Host Organization



Network – 49 states, PR, DC

Federal Partners



DOE



DOD



EPA

ITRC Industry Affiliates Program



Academia

Community Stakeholders

Disclaimer

Partially funded by the US government

ITRC nor US government warranty material

ITRC nor US government endorse specific products

ITRC materials available for your use – see [usage policy](#)

Meet Your Trainers



Tom Fox, Colorado DPHE
tom.fox@state.co.us



Matt Lahvis, Shell
matthew.lahvis@shell.com



Steve Gaito, AECOM
steven.gaito@aecom.com



Diana Marquez
dianaymarquez@gmail.com



Lloyd Dunlap
dunlaplloyde@gmail.com



Richard Spiese, Vermont DEC
Richard.Spiese@vermont.gov



Laura Trozzolo, TRC Companies
LTrozzolo@trccompanies.com



Mark Lyverse, AECOM
Mark.Lyverse@aecom.com

Key ITRC Petroleum Hydrocarbon Guidance

PVI (Petroleum Vapor Intrusion)

<https://projects.itrcweb.org/PetroleumVI-Guidance/>

LNAPL (Light Non-Aqueous Phase Liquids)


<https://lnapl-3.itrcweb.org/>

TPH (Total Petroleum Hydrocarbons)

<https://tphrisk-1.itrcweb.org/>

Hydrocarbons Sites (Effective Application of Guidance Documents)

<https://hyd-1.itrcweb.org/>



Where Does This Training Apply?



All types of petroleum. Large or small sites.

Course Training Goals

Overview of key issues to help identify and manage Total Petroleum Hydrocarbons (TPH), Light Non-Aqueous Phase Liquids (LNAPL), and Petroleum Vapor Intrusion (PVI) risks TOGETHER

Introduce what's contained in the ITRC petroleum hydrocarbon guidance documents and highlight where they overlap

Present latest science to support best practices for site investigation (CSM development), risk management, and regulation development

Emphasize the importance of biodegradation in risk management decision making

Course Outline

Fundamentals of petroleum hydrocarbons

Petroleum chemistry

How are TPH, LNAPL, and PVI related?

Building an integrated CSM


What is a CSM... what is its purpose?

When is a CSM complete?

Identifying and managing the risks from petroleum hydrocarbons


Defining LNAPL risks based on acute, saturation, composition, or aesthetic concerns

Fundamentals of Petroleum Hydrocarbons




The Chemistry of Petroleum Fuels

- Petroleum fuels (gasoline, motor oil, etc.) are distilled from the heating (refining) of crude oil
- Refined fuels contain 1000s of hydrocarbons and widely different compositions
- Petroleum and non-petroleum fuel composition are commonly quantified from TPH analyses
- TPH analyses measure petroleum hydrocarbons that are present in LNAPL, sorbed, dissolved, and vapor phases



Source: Haley & Aldrich

Refined Fuels and Oils are Complex Mixtures




Source: TPH Criteria Working Group vol. 5 (1999)

What is Light Non-Aqueous Phase Liquid (LNAPL)?

LNAPL is a fluid that has a density less than water and is immiscible with water

LNAPL can be difficult to assess and recover once released to the subsurface

LNAPL contains >99% of the hydrocarbon source mass and often acts as a long-term source of vapor, groundwater, and soil contamination




How Petroleum Exists in the Environment



LNAPL Location

Most "stuck" in soil pores



Vadose Zone



Capillary Zone



Saturated Zone




ITRC 2015

LNAPL Partitioning

~99% of mass remains LNAPL!

(<0.5% in air or water, or on soil surfaces)



<70% could be mobile LNAPL
(reduces over time)

<50% of that is recoverable
(reduces over time)


30 – 100% of LNAPL mass
becomes residual
(varies by fuel and soil type, degradation)

What is TPH (Total Petroleum Hydrocarbons)?

TPH is present in soil gas, pore water, sorbed phase, and LNAPL related to:


- Original LNAPL release
- LNAPL after weathering
- Hydrocarbons dissolving (leaching) from the parent
- LNAPL into porewater, groundwater, or surface water
- Hydrocarbons volatilizing from the parent LNAPL, groundwater, or pore water to soil vapor

TPH can be fractionated to understand aliphatic and aromatic classes for different carbon ranges



Source: ITRC TPHRisk-1 Figure 4-3

TPH Versus LNAPL (Migrating, Mobile, and Residual)



$$TPH > C_{sat} \Rightarrow LNAPL$$

C_{sat} is a TPH concentration threshold that indicates when residual LNAPL is potentially present in soil (effective aqueous solubility & vapor pressure limits)

C_{sat} varies with fuel type (gasoline, diesel) & soil type (sand, silt, clay)

What is Petroleum Vapor Intrusion (PVI)?


Migration of vapors from petroleum-related contaminants from the subsurface into overlying buildings, causing a potential public health concern

Often a key risk driver at petroleum release sites, driving environmental clean-up


Strongly influenced by source type (fuel type, LNAPL vs. dissolved phase)

Differs from chlorinated vapor intrusion (CVI)

- petroleum vapors are highly susceptible to biodegradation
- can create certain acute risks (explosion hazards) from the production of methane during biodegradation




Building an Integrated Conceptual Site Model (CSM)



ITRC TPHRisk-1 Figure 5-1. Conceptual site model (visual depiction) showing the migration pathways of petroleum from source to receptors.


What Is a CSM and What's Its Purpose?

- A CSM is used to:
 - ✓ identify potential sources, pathways, receptors, for current and reasonably anticipated future site conditions
 - ✓ define LNAPL concerns, goals, and objectives
 - ✓ support decision making (site screening, further data collection, risk management)
- A CSM (presented as text with supporting diagrams) is constantly updated with new site information (development and application are an iterative process)



CSM: General Petroleum Hydrocarbon Distribution and Exposure Pathways


- PHASE**
- NAPL (non-aqueous phase liquid)
 - Air/Vapor
 - Water
 - Sorbed
- MEDIA**
- EXPOSURE PATHWAY**



Source: modified from HIDOH Case Study #1, Figure 1-3 (HIDOH 2018)

hydrocarbon distributions in groundwater and the vadose zone will vary depending on hydrocarbon


ITRC's Hydrocarbons CSM Development Checklist

ITRC Petroleum Risk Evaluation Checklist			
Screening Questions	References (all PVI references can be accessed through links on page 12 of the Tech Reg)	Applicable to Scenario? (Y/N)	Notes
STEP 1: Emergency Response/Initial Investigation (LNAPL: does not address emergency responses)			
Was emergency response required?	PVI Figure 1-1 TPH Section 2.4 TPH Section 9.2		maintain surveillance of any location where an exposure has already occurred (identifies preferential migration pathways)
STEP 2: Site Characterization to create the Conceptual Site Model			
How to create an Initial Conceptual Site Model.	LNAPL Section 4 - 4.3 TPH Section 5 PVI Section 2.3		
Where is the release source location? Is there an ongoing release of LNAPL?	TPH Table 5-1 LNAPL Section 3.2.1 PVI Section 3.1.4		
Site Type - Classify site as either: <ul style="list-style-type: none"> • Petroleum UST/AST Site: Petroleum UST/AST sites generally include: a) facilities used for vehicle fueling (e.g., gas stations, municipal fleet yards, bus terminals, fire stations, etc.) and b) commercial/home heating oil tanks. Fuels and oils at these sites are typically stored in USTs, but could be stored in similarly sized ASTs. • Petroleum Industrial Site: Includes: a) bulk fuel terminals, b) refineries, c) exploration and production sites, d) crude oil and product pipelines, and e) former manufactured gas plants. 	PVI Section 2.5 PVI Table 2-2 PVI Section 3.1.1 PVI Appendix E		

<https://hyd-1.itrcweb.org/petroleum-risk-evaluation-checklist/>

Not All CSMs Are Created Equal

- The CSM should be tailored to site conditions and identifying and managing potential risks
- Sites with complex hydrogeology and/or high technical or reputational risks require a more detailed CSM!



When is the CSM Complete?


Have relevant sources, pathways, and current/future receptors been identified?

Is the information sufficient to bound uncertainties related to changes in site conditions (e.g., spatiotemporal variability in constituent concentrations, changes in land use)*


Is the information sufficient to support the identification of LNAPL goals, concerns and objectives (described in next section)?

*** greater uncertainty may be ok at low-risk sites (e.g., urban gas station with no drinking water wells)**

Identifying & Managing Risks from Petroleum Hydrocarbons



Identifying LNAPL Concerns (4 Types)



Terminology

Remedial Concern

LNAPL condition or potential condition:

- additional LNAPL migration (saturation concern)
- safety or health/environment risk (composition concern)
- seep, sheen, stain, odor (aesthetic/other concern)


Remedial Goals

Desired LNAPL outcome of remediation (e.g., reduce COC concentrations to below clean-up levels)



Remedial Objectives

Describes how the goal will be accomplished and must be linked to the technology(ies) to be used (e.g., target volatiles COCs using soil vapor extraction - SVE)


Concerns Differ Based on General LNAPL Scenario




Condition: LNAPL in wells, migrating
Concern: LNAPL saturation




Condition: LNAPL in wells, mobile
Concern: LNAPL composition, saturation



Condition: No LNAPL in wells, residual
Concern: LNAPL composition



Contrast Between Saturation and Composition Goals



Reducing LNAPL saturation will not affect composition (chemical concentrations in groundwater or soil gas) unless virtually all LNAPL is removed!!




Key Message 1

LNAPL bodies typically stabilize quickly.


Mobile LNAPL in wells does not mean that the LNAPL body is migrating

LNAPL Gradient: Finite Releases Flatten Over Time

Migrating
LNAPL



- 30-60% of the pore volume occupied by LNAPL will remain as residual
- Finite release means finite extent
- Abating the release promotes stability



Plume stability occurs when the perimeter of the plume attains sufficient size or location such that attenuation mechanisms equal or exceed the mass flux at that boundary

What We Have Observed at LNAPL Sites

**Migrating
LNAPL**

LNAPL can initially spread at rates higher than the groundwater flow rate due to large LNAPL hydraulic heads at time of release

**Mobile
LNAPL**

LNAPL can spread opposite to the direction of the groundwater gradient (radial spreading)

After LNAPL release is abated, the petroleum hydrocarbon mass becomes finite and the LNAPL body becomes stable. Stability is generally achieved within a short period of time (<5 years)

Evidence To Demonstrate LNAPL Is Not Migrating

Migrating
LNAPL

Mobile
LNAPL

Stable/decreasing LNAPL footprint (areal distribution or thickness of LNAPL in monitoring wells over time that accounts for seasonal changes in water-table elevation)

Stable/decreasing COC concentrations and plume lengths over time

Low LNAPL transmissivities (such as less than 0.8 ft²/d) when not adjacent to a surface water body (ITRC, 2018)

Residual LNAPL observed beyond the footprint of mobile LNAPL

LNAPL thickness (in MW) exceeds a critical thickness for migration (LNAPL and soil type dependent unconfined conditions only)

Society of Brownfield Risk Assessment - SOBRA, 2023

Questions



Key Message 2

Apparent LNAPL thicknesses in wells is affected by water table fluctuations and the LNAPL hydrogeologic condition.

Thickness of Mobile LNAPL \neq Thickness in Formation

Mobile &
Residual
LNAPL




Image: ITRC LNAPL-3 Training

- LNAPL volumes based on pancake model (uniform saturations) are over estimated
- For a given LNAPL thickness, LNAPL saturations and volumes are different for different soil types (greater for coarser-grained soils)


Thickness of Mobile LNAPL \neq Thickness in Formation
(Vertical Distribution is a Shark Fin, Not a Pancake)

Fluctuations in Groundwater Levels

Migrating LNAPL

Mobile LNAPL

Gauged LNAPL Thickness in MWs Over Time (Refinery)




From API Interactive NAPL Guide, 2004

Fluctuations in GW Levels Can Make LNAPL Appear to Be Migrating When It Is Not

LNAPL Thickness Change with Water Table Fluctuation






Mobile LNAPL



Apparent LNAPL Thickness

Apparent LNAPL Thickness Is Not a Good Indicator of LNAPL Thickness in Formation

Mobile LNAPL




Key Message 3

LNAPL can be in the formation
when it is not accumulating in a
well




Identification of Residual LNAPL is Critical For PVI Screening and Risk Assessment

Residual LNAPL sources represent similar PVI risks as mobile or migrating LNAPL sources and can be difficult to identify



Potential Indicators of Residual LNAPL (mainly gasoline)




Indicator	Comments
Groundwater	
<ul style="list-style-type: none"> • benzene: > 1 - 5 mg/L • TPH_(gasoline): > 30 mg/L • BTEX: > 20 mg/L • current or historical presence of LNAPL (including sheens) 	<ul style="list-style-type: none"> • no specific hydrocarbon concentration in groundwater that defines all LNAPL types because: <ul style="list-style-type: none"> - varying product types - degrees of weathering
Soil	
<ul style="list-style-type: none"> • current or historical positive shake test results • benzene > 10 mg/kg • ITRC: TPH_g > 250 - 500 mg/kg; US EPA OUST: TPH_g > 100 (fresh); TPH_D > 250 (weathered, diesel) • ultraviolet light (UV) or laser-induced fluorescence (LIF) response in LNAPL range • PID or FID readings > 500 ppm • Soil Gas Readings Low (O₂), High (CO₂, CH₄, Aliphatics) 	<ul style="list-style-type: none"> • use of TPH soil concentrations as LNAPL indicators should be exercised with caution: <ul style="list-style-type: none"> - can be affected by the presence of soil organic matter - TPH soil concentrations are not well correlated with TPH or O₂ soil gas concentrations
Location relative to UST system (e.g., tank, dispenser, pipework) or AST	
<ul style="list-style-type: none"> • adjacent (e.g., < 20 feet) from a known or suspected LNAPL release or petroleum UST/AST equipment 	<ul style="list-style-type: none"> • probability of encountering LNAPL increases closer to release location

Other General Indicators of Residual LNAPL

Residual
LNAPL

Soil gas indicators include:

- Oxygen (O_2) < 5% vol/vol
- Carbon dioxide (CO_2) > 15% v/v
- Methane > 1% v/v
- Benzene > 1,000 mg/m³
- Hexane > 100,000 mg/m³
- C₅ – C₈ aliphatics > 100,000 mg/m³
- C₉ – C₁₂ aliphatics > 10,000 mg/m³



LNAPL Characterization Tools

Migrating
LNAPL

Mobile &
Residual
LNAPL

Data Need	Description	Examples	References
LNAPL Delineation	Presence	LIF (UVOST/OIP), soil borings (visual, PID, shake tests, dye tests), soil concentrations, dissolved-phase concentrations, soil vapor (VOCs and/or biogenic gases)	LNAPL-3: Table 3-2
	Mobile	Monitoring wells, core LNAPL saturations	LNAPL-3: Section 3.5
LNAPL Properties	Chemical	Site history, gas chromatography, biomarkers, distillation, PIANO	LNAPL-3: Table 4-2
	Physical	Density, viscosity, interfacial tension	LNAPL-3: Table 4-2
LNAPL Hydrogeologic Condition	Unconfined, confined, or perched	Hydrographs, diagnostic gauge plots	LNAPL-3: Section 3.4
LNAPL Stability	Apply multiple lines of evidence	Release date, mobile LNAPL extent, dissolved and/or vapor footprint, hydrographs,	LNAPL-3: Table 4-1
LNAPL Recoverability	LNAPL transmissivity	Baildown, manual skimming, LNAPL recovery system evaluations	LNAPL-3: Appendix C, Section 2
Natural Biodegradation Processes	NSZD	Gradient, CO ₂ flux, temperature methods, LNAPL composition, polar metabolites	LNAPL-3: Appendix B, Section 4

[ITRC DNAPL Site Characterization](#) and [Tools Selection Worksheet](#).


LIF: Laser Induced Fluorescence
 UVOST: Ultraviolet Optical Screening Tool
 OIP: Optical Image Profiler

PID: Photoionization Detector
 PIANO: n-Paraffins (P), Iso-paraffins (I), Aromatics (A),
 Naphthenes (N) and Olefins (O)

Key Message 4

Biodegradation helps LNAPL bodies and groundwater plumes stabilize and/or shrink

Biodegradation Is the Ultimate Contributor to LNAPL Stability




Mobile & Residual LNAPL

Migrating LNAPL

Biodegradation Is A Primary Contributor to LNAPL Stability

Migrating
LNAPL

Hydrocarbons degrade faster in the presence of oxygen (aerobic conditions) than without it (anaerobic conditions)





- Anaerobic processes are important (account for majority of LNAPL weathering in saturated zone)
- Biodegradation, volatilization, and dissolution are primary processes involved in LNAPL weathering
- Weathering of LNAPL evidenced by changes in dissolved and vapor phase composition
- Some hydrocarbons degrade more quickly than others

Biodegradation Is a Primary Contributor to LNAPL Stability

Migrating LNAPL


- Microbes that degrade hydrocarbons are ubiquitous
- Biodegradation occurs in the saturated and vadose zones in:
 - LNAPL – using enzyme surfactants
 - Aqueous phase -- primary location where bacteria reside



Primary NSZD Processes

Migrating LNAPL

Mobile & Residual LNAPL



ITRC LNAPL-1 Figure 1-1. Example LNAPL Source Zone

- Primary saturated-zone and LNAPL processes include:
 - Anaerobic biodegradation
 - Degassing and ebullition
 - Direct outgassing from microbes in contact with LNAPL
 - Dissolution
 - Volatilization
- Primary vadose-zone processes include:
 - Methane (CH₄) oxidation (involving oxygen – O₂) to carbon dioxide (CO₂)
 - Aerobic biodegradation of VOCs


Methane oxidation and aerobic biodegradation in the vadose zone account for >99% of LNAPL mass loss

NSZD Rates Can Compete with Certain Engineered Remediation Systems

Migrating LNAPL

Mobile & Residual LNAPL

Important to factor in NSZD rate into remedial decision making to minimize unnecessary remediation



Kulkarni et al., 2022
 Site Average NSZD Rates:
 various methods
 (40 LNAPL sites)
 90% > 1600 L/ha/yr
 (170 gal/acre/yr)

NSZD in Context with CSM and Remedial Decision Making

NSZD – An important part of the petroleum NAPL CSM

Refine the CSM with quantification of bulk petroleum NAPL and/or chemical constituent loss rates

Determine whether NSZD is sufficient to address risk/concerns

Determine the NAPL footprint using vadose zone indicators of biodegradation


Compare NSZD to historical or potential future remedial activities

Support estimates of source zone remedial timeframes

Assess NAPL stability through application of a mass balance of NSZD mass losses and measured mobile NAPL flux



Migrating
LNAPL




Mobile &
Residual
LNAPL

Hydrocarbon Biodegradation Can Lead to Formation of Polar Metabolites

Mobile & Residual LNAPL


- Intermediate (anaerobic) biodegradation products
- Challenge assessing risk because of limited toxicity information for individual metabolites and mixtures



TPH-gas plume lengths (Shih 2004)

- Median: 220 feet
- Max: ~600 feet

- Different properties from HCs
 - O₂
 - Polar
 - More soluble / mobile




Solubility of n-Hexane vs Metabolites

Chemical	Formula	Boiling Point (°C)	Solubility (µg/L)
n-Hexane	C ₆ H ₁₄	69	9.5E+03
2-Hexanone	C ₆ H ₁₂ O ₁	128	7.7E+06
Hexanoic Acid	C ₆ H ₁₂ O ₂	205	5.8E+06


How Can You Identify Polar Metabolites?

Identify metabolites using:

- Analysis w/ & w/out SGC
- Chromatogram pattern
- Conceptual site model (e.g., more mobile/soluble)



Metabolites detected as TPH when silica gel cleanup (SGC) not used




ITRC TPHRisk-1: Figure A5-5 (data from CA site)

Biodegradation is Also a Key Process Limiting PVI

Mobile &
Residual
LNAPL

- Hydrocarbons (and methane) attenuate rapidly in the presence of O_2
- At some distance above the source, rates of biodegradation for most COCs exceeds rates of upward migration by physical processes (e.g., diffusion)
 - ✓ Aerobic: utilize O_2 , produce CO_2 and H_2O
 - ✓ Anaerobic: utilize CO_2 and H_2 , produce CH_4
 - ✓ Produce heat
 - ✓ Acclimate/adapt relatively quickly



Source: G.T. Ririe, 2013


Key Message 5

**PVI IS PRIMARILY
ASSOCIATED WITH LNAPL
SOURCES: SOURCE TYPE
MATTERS**

Site Screening Is Important for PVI: Vertical Screening Distance Concept

Mobile & Residual LNAPL

Source Type Matters !!





Which Buildings Screen In – Lateral Inclusion Zone

Mobile &
Residual
LNAPL

Which buildings get screened in & which screening distance to apply?

30 feet* from edge of PVI source to building unless site data prove otherwise

*30 feet is conservative given that lateral screening distances should be roughly the same as the vertical screening distances of 5 and 15 ft



Screening Distances Do Not Apply to Certain Buildings If Precluding Factors Are Present

Mobile &
Residual
LNAPL


Definition: Site-specific conditions which preclude (prevent) the application of site screening

- ✓ Preferential pathways (e.g., utilities, conduits, fractured rock connecting vapor source to building)
- ✓ Certain fuel types (e.g., gasoline containing lead scavengers or > 10% ethanol by volume)
- ✓ Expanding/advancing plume with potential to migrate below buildings or enter the “lateral inclusion zone”
- ✓ Certain soil types (arid soils or soils with very high organic matter content)

*US EPA (2015) also lists certain building types with large foundations > 66 feet on each side

For Buildings That Do Not Screen Out for PVI: Soil Gas → Subslab Vapor → Indoor Air



Mobile &
Residual
LNAPL




Challenges of Receptor (Building) Characterization

Mobile & Residual LNAPL

VOCs in Background Indoor Air (Reporting Limits in $\mu\text{g}/\text{m}^3$)



Background concentrations in indoor air (benzene) can exceed Risk (based) Screening Level (RSL) for 10^{-6} Target Risk



Groundwater sampling [4.2.2.1]

Soil sampling [4.2.2.6]

Soil Gas sampling [4.2.2.2]

Crawl space sampling [4.2.2.5]

Indoor air sampling [4.2.2.3]

Ambient air sampling [4.2.2.4]

Difference in sampling between petroleum and chlorinated

Supplemental Tools & Data Useful for VI Investigations [Appendix G]

Analysis Methods [Appendix G]

Questions




Key Message 6

TPH is not necessarily “total”,
not necessarily all from petroleum,
& not necessarily all hydrocarbons

TPH in the Environment

TPH is a measurement that helps focus the risk assessment:

- ✓ Defined by the analytical method used to measure it
- ✓ Provides an approximate concentration of the total hydrocarbons in a complex mixture
- ✓ Provides information about the type, volume, and distribution of hydrocarbons in LNAPL




C# 11 17 23

ITRC TPHRisk-1 Figure A5-4

Four TPH Methods Will Yield Four Different Results

Mobile &
Residual
LNAPL




And will measure "TPH" for non-petroleum hydrocarbons!


Not All TPH Is Petroleum Hydrocarbon

Mobile & Residual
LNAPL

Before Silica Gel Cleanup



After Silica Gel Cleanup



Selecting Appropriate TPH Lab Methods

Category	Example Methods	Application	Pros	Cons
Bulk TPH	EPA 8015/8260, TX1005, KS LRH/MRH/HRH	Initial site assessment, overall extent	Inexpensive	May overpredict hydrocarbons, limited risk assessment usability
Fractionation	TX1006, MADEP VPH/EPH, WA Dep Ecology	Improve site conceptual model	Better define fate/transport and risk characteristics	Expensive
Silica Gel Cleanup	EPA Method 3630C with Bulk TPH Methods	Remove non- hydrocarbons, including polar metabolites, from results	Better define extent, fate/transport, and risk of hydrocarbons	Removes polar metabolites from the assessment

TPH provides an approximate concentration of total hydrocarbons in a medium:

- ✓ Provides information on hydrocarbon size and distribution
- ✓ Result will vary by analytical method used to measure it
- ✓ Result may include non-hydrocarbons depending on method used


REMEMBER Key Message 5: TPH is not necessarily “total”, not necessarily all from petroleum, and not necessarily all hydrocarbons

Key Message 7

Composition of the fuel matters
for assessing the risk of mobile or
residual LNAPL

Bulk TPH – What's In That Number?


Mobile & Residual LNAPL



Note that the first dotted line on the chromatograms is at C10, the second at C28


Unique Characteristics of TPH Effect Exposure

- PHASE**
- NAPL (non-aqueous phase liquid)
 - Air/Vapor
 - Water
 - Sorbed
- MEDIA**
- EXPOSURE PATHWAY**




Source: modified from HIDOH Case Study #1, Figure 1-3 (HIDOH 2018)


Individual Compound Approach




Whole Product



Fraction/Surrogate




Tiered TPH Risk Assessment Framework



Assessing Risk from TPH


Mobile &
Residual
LNAPL

- TPH is a complex mixture
- Unique fate and transport properties of TPH affect how risk should be assessed
- Varying types of TPH data lend themselves to a tiered assessment approach
 - **Tier 1 Screening Level Risk Assessment:** bulk TPH data and indicator compounds
 - **Tier 2/3 Site-specific Risk Assessment:** TPH fraction data
- Understanding analytical data, CSM, and regulatory framework is critical in appropriately assessing risk



Source: Haley & Aldrich


Risk Management



Petroleum Risk Management Options

Risk Management Option
Additional Data Collection
Remedial Action (e.g., cleanup based on LNAPL or dissolved-phase concerns)
Mitigation (e.g., PVI active or passive systems)
Engineering Controls (e.g., barrier wall)
Institutional Controls (e.g., deed restrictions)

Select Remedial Goals



Select Remedial Goals

- **Saturation Goal**

- Objective: LNAPL mass control/recovery
- Examples: stop LNAPL migration by containing LNAPL or Reduce LNAPL saturation by recovering LNAPL

- **Composition Goal**

- Objective: LNAPL phase change
- Example: Change LNAPL characteristics by phase change


- **Aesthetic Goal**

- Objective: eliminate cause (LNAPL Saturation or Composition)
- Example: stop LNAPL from seeping to river




Select Remedy That Aligns With Remedial Goals

Remedial Technology Grouping & Overlap



Identify Performance Metrics & Endpoints



Performance Metrics: Example – ASTM WK78867

Example Performance Metrics	
System Related	Subsurface Related
<ul style="list-style-type: none">• TPH/COC concentration in influent/effluent (C)• Fluid recovery rates (LNAPL, water, gas)• LNAPL to vapor or water ratios (S)• Flow rate, pressure/vacuum, temperature (S or C)• Drawdown, water-level mounding (S or C)• Radius of influence (C or S)	<ul style="list-style-type: none">• Groundwater, soil, or soil-gas concentrations over time, space (C)• COC mass flux or discharge in groundwater or soil vapor (C)• LNAPL presence or thickness in wells (S)• LNAPL transmissivity (S)• Electron acceptor distribution (oxygen) (C)

* From WK78667 Draft ASTM Guide for Advancing Stalled Corrective Action Sites Toward Site Closure

(S) = Saturation Concern
(C) = Composition Concern

Endpoints (Transition Thresholds): Example – ASTM WK 78667

Example Transition Thresholds

- LNAPL transmissivity below an ITRC (2018) threshold of 0.1 to 0.8 ft²/day (S)
- Recovery of 95% of LNAPL based on a decline curve analysis (ITRC, 2018) (S)
- Concentrations or mass discharge at (or approaching) established regulatory target levels within accepted statistical certainty (C)
- Active mass recovery rates similar to (or less than) natural source-zone depletion rates (ASTM, 2022) (S)
- Active attenuation rates similar to (or less than) natural attenuation rates (ASTM, 2022) (C)
- No (or limited) rebound in concentrations or mass following temporary termination of corrective action (partial or complete) (S and/or C)
- Mass removal or concentration attenuation rates by active recovery approaching asymptotic levels while ratio of GHG emissions per unit reduction in mass or concentration is rapidly increasing (S and/or C)
- Mass removal or concentration attenuation rates by active recovery approaching asymptotic levels while ratio of costs per unit reduction in mass or concentration is rapidly increasing (S & C).

(S) = Saturation Concern

(C) = Composition Concern

* From WK78667 Draft ASTM Guide for Advancing Stalled Corrective Action Sites Toward Site Closure

Training Summary

The characterization of TPH, LNAPL, and PVI requires an integrated approach that is communicated through a CSM


TPH key messages

- TPH is defined by analysis
- TPH analysis characterizes nature/extent and whether biodegradation is occurring (i.e., presence of petroleum metabolites)
- Type of TPH analysis depends on site investigation goals (i.e., fractionated TPH analysis provides results that have associated toxicity values; therefore, can quantify human health risks)

Training Summary

LNAPL key messages


- LNAPL is the source of long-term vapor, sorbed and dissolved phases
- LNAPL can be present in the soil pores even if not visible in wells
- LNAPL bodies typically stabilize quickly



Training Summary

LNAPL key messages


- Mobile LNAPL in wells does not mean that the LNAPL body is migrating (or recoverable)
- LNAPL thickness in wells is affected by soil type, water table fluctuations, and the LNAPL hydrogeologic condition
- Biodegradation processes deplete LNAPL source mass and helps stabilize LNAPL bodies
- Remedial technology selection based on the LNAPL concern(s): saturation, composition, and/or aesthetic



Training Summary

PVI key messages


- Biodegradation in the vadose zone limits the potential for PVI and serves as the basis for lateral and vertical screening distances
- PVI risks are mainly associated with LNAPL (gasoline)



Training Summary

PVI key messages

- Proper identification of residual LNAPL sources is critical
- Site characterization should focus on the vadose zone given the high likelihood of encountering gasoline-related COCs in indoor air above risk-based screening levels



Questions

PVI

<https://projects.itrcweb.org/PetroleumVI-Guidance/>

LNAPL


<https://lnapl-3.itrcweb.org/>

TPH

<https://tphrisk-1.itrcweb.org/>

Hydrocarbons Sites

<https://hyd-1.itrcweb.org/>



Certificate of Completion <https://www.clu-in.org/conf/itrc/Hydrocarbons/>
emailed after you complete the Feedback Form

References and Citations

- API (American Petroleum Institute), 2004. API Interactive LNAPL Guide Version 2.0.4. API Publishing Services, 1220 L. Street, NW, Washington, DC. February 2006. <https://www.api.org/oil-and-natural-gas/environment/clean-water/ground-water/lnapl/interactive-guide>.
- API (American Petroleum Institute), 2017. Quantification of vapor phase-related natural source zone depletion processes. American Petroleum Institute Publication #4784. API Publishing Services, 1220 L. Street, NW, Washington, DC. May 2017. https://store accuristech.com/standards/api-publ-4784?product_id=1984357.
- ASTM International, 2006. Standard Guide for Development of Conceptual Site Models and Remediation Strategies for Light Nonaqueous-Phase Liquids Released to the Subsurface. Standard Guide E2531-06. ASTM International, West Conshohocken, PA.
- Dawson, H.E., and T. McAlary, 2009. A compilation of statistics for VOCS from post-1990 indoor air concentration studies in North American residences unaffected by subsurface vapor intrusion. *Groundwater Monit. Remed.*, 29, 60-69. <https://doi.org/10.1111/j.1745-6592.2008.01215.x>.
- Hua Y., He, X, Xie, W., Xiong, J., Sheng, H., Guo, S., Huang, C., Zhang, D., and K. Zhang. 2014. Elastase LasB of *Pseudomonas aeruginosa* promotes biofilm formation partly through rhamnolipid-mediated regulation. *Can J. Microbiol.* 60, 227-235. <https://doi.org/10.1139/cjm-2013-066>.
- ITRC (Interstate Technology & Regulatory Council). 2023. Effective Application of ITRC Guidance to Hydrocarbons Sites HYD-1. Washington, D.C., www.itrcweb.org.
- ITRC (Interstate Technology & Regulatory Council). 2023. Effective Application of ITRC Petroleum Risk Evaluation Checklist. Washington, D.C., <https://hyd-1.itrcweb.org/petroleum-risk-evaluation-checklist/>.
- ITRC, 2018. LNAPL-3: LNAPL Site Management – LCSM Evolution, Decision Process, and Remedial Technologies. Interstate Technology and Regulatory Council. March 2018. <https://lnapl-3.itrcweb.org/>

References and Citations

- ITRC (Interstate Technology & Regulatory Council). 2018. TPH Risk Evaluation at Petroleum-Contaminated Sites. TPHRisk-1. Washington, D.C.: Interstate Technology & Regulatory Council, TPH Risk Evaluation Team. <https://tphrisk-1.itrcweb.org>
- ITRC (Interstate Technology and Regulatory Council) 2009. Evaluating Natural Source Zone Depletion at Sites with LNAPL. Interstate Technology and Regulatory Council, Washington, D.C., <https://www.itrcweb.org/guidancedocuments/lnapl-1.pdf>.
- Kulkarni, P.R., Walker, K.L., Newell, C.J., Askarani, K.K., Yue, L., and T.E. McHugh. 2022. Natural source zone depletion (NSZD) insights from over 15 years of research and measurements: A multi-site study. Water Research. 225, 119170. <https://doi.org/10.1016/j.watres.2022.1191>.
- Kulkarni, P.R., McHugh, T.E., Newell, C.J., and S. Garg, 2015. Evaluation of source-zone attenuation Palaia, T., and S. Park. 2023. Incorporating Natural Source Zone Depletion (NSZD) into the Site Management Strategy. In Environmental Contamination Remediation and Management, Advances in the Characterisation and Remediation of Sites Contaminated with Petroleum Hydrocarbons, Chapter 13. Editors J. Garcia-Rincon, E. Gatsisos, R.J.Lenhard, E.A. Atekwana, and R. Naidu. Springer. https://link.springer.com/chapter/10.1007/978-3-031-34447-3_13.
- Palaia, T. 2017. A Comparison of Natural Source Zone Depletion and Active Remediation Rates. Presented at the 7th International Contaminated Site Remediation Conference - CleanUp 2017, Melbourne Australia, September 13, 2017. https://inis.iaea.org/search/search.aspx?orig_q=RN:52085940.
- SOBRA (Society of Brownfield Risk Assessment), 2023. Light Non-Aqueous Phase Liquid – Guidance Notes for their Assessment in Contaminated Land Scenarios in the UK . 3. LNAPL MOBILITY SCREENING TOOL. Version 1.0, April 2023. https://sobra.org.uk/?pmpro_getfile=1&file=2023/06/SOBRA-NAPL-Mobility-Tool-080523-Final-combined-page-12-edited&ext=pdf.
- USEPA (U.S. Environmental Protection Agency). 2011. Background Indoor Air Concentrations of Volatile Organic Compounds in North American Residences (1990–2005): A Compilation of Statistics for Assessing Vapor Intrusion. US Environmental Protection Agency Office of Solid Waste and Emergency Response Report EPA 530-R-10-001, June, 2011. <https://www.epa.gov/sites/default/files/2015-09/documents/oswer-vapor-intrusion-background-report-062411.pdf>.
- Zemo, D. A. 2016. White Paper: Analytical Methods for Total Petroleum Hydrocarbons (TPH). Washington, D.C.: Prepared for American Petroleum Institute (API).