

## Welcome to the CLU-IN Internet Seminar

NARPM Presents...Vapor Intrusion Issues at the Hill Air Force Base Sponsored by: EPA Office of Superfund Remediation and Technology Innovation

Delivered: March 24, 2011, 2:00 PM - 4:00 PM, EDT (18:00-20:00 GMT)

#### Instructors:

Sandra Bourgeois, U.S. EPA Region 8 (bourgeois.sandra@epa.gov or (303) 312-6666)

Maple Barnard, U.S. EPA Region 8 (barnard.maple@epa.gov or (303) 312-6321)


Moderator:

Jean Balent, U.S. EPA, Technology Innovation and Field Services Division (balent.jean@epa.gov or (703) 603-9924)

Visit the Clean Up Information Network online at www.cluin.org

#### Housekeeping

- Please mute your phone lines, Do NOT put this call on hold
   press \*6 to mute #6 to unmute your lines at anytime
- Q&A
- Turn off any pop-up blockers
- Move through slides using # links on left or buttons



- · This event is being recorded
- Archives accessed for free http://cluin.org/live/archive/

2

Although I'm sure that some of you have these rules memorized from previous CLU-IN events, let's run through them quickly for our new participants.

Please mute your phone lines during the seminar to minimize disruption and background noise. If you do not have a mute button, press \*6 to mute #6 to unmute your lines at anytime. Also, please do NOT put this call on hold as this may bring delightful, but unwanted background music over the lines and interupt the seminar.

You should note that throughout the seminar, we will ask for your feedback. You do not need to wait for Q&A breaks to ask questions or provide comments. To submit comments/questions and report technical problems, please use the? Icon at the top of your screen. You can move forward/backward in the slides by using the single arrow buttons (left moves back 1 slide, right moves advances 1 slide). The double arrowed buttons will take you to 1st and last slides respectively. You may also advance to any slide using the numbered links that appear on the left side of your screen. The button with a house icon will take you back to main seminar page which displays our agenda, speaker information, links to the slides and additional resources. Lastly, the button with a computer disc can be used to download and save today's presentation materials.

With that, please move to slide 3.

# CASE STUDY VAPOR INTRUSION HILL AIR FORCE BASE, UT

Other Federal Agency Lead





Sandra Bourgeois, EPA R8 Annette Barnard, EPA R8 March 24, 2011


0

## OVERVIEW OF HILL AFB VAPOR INTRUSION PROGRAM

- History
- Program Overview
- Mitigation
- Challenges and Optimization
- Community Involvement
- Exit Strategy
- Case Studies
  - 1,2 DCA
  - Pressure Control Example
  - Preferential Flow








	le Unit Sumn	ilary offic												1/2011
		OU-1	OU-2	OU-3	OU-4	OU-5	OU-6	OU-7	OU-8	OU-9	OU-10	OU-11	OU-12	OU-13
Affected	Communities	South Weber	South Weber	Hill AFB (soil contamination only)	South Weber Riverdale	Sunset Clinton	Riverdale	Hill AFB (soil contamination only)	Layton (also includes groundwater below OU-3 and OU-7)	Hill AFB (consists of 3 unrelated sites)	Clearfield Sunset Clinton	Hill AFB	Roy	Hill AFB
Approx.	Off Base	53	19		32	288	19		434	-	142		123	
Acres Affected	On Base	57	5	12	19	63	31	1	301	23	12	12	10	32
Approx. Ho	mes in the Area	30	Less than 10	-	Less than 10	750	50-100	-	1,150	-	300-350	-	300-350	100
Project Manager		Barbara 'B' Hall 801-777-0493	Kyle Gorder 801-775-2559	Lance Kovel 801-775-5242	Rob Wallace 801-777-3684	Mark Roginske 801-775-3651		Lance Kovel 801-775-5242	Lance Kovel 801-775-5242	Shannon Smith 801-775-6913	Rob Wallace 801-777-3684	Lance Kovel 801-775-5242	Mark Roginske 801-775-3651	Rob Wallace 801-777-3684
Primary Contaminants		Cis-1,2-DCE Arsenic	TCE	Petroleum- based products, cleaning solvents, sodium hydroxide, metals	TCE	TCE	TCE	Chromium Cadmium	TCE DCA cis-1,2 DCE chlorobenzene	TCE PCE cis-1,2 DCE CTCL	TCE PCE cis-1,2 DCE	BTEXN TCE MTBE	TCE CT	PCBs
CERCLA Stage		Remedial Action	Remedial Action	Remedial Action	Remedial Action	Remedial Action	Remedial Action	Remedial Action	Remedial Action	Proposed Plan	Feasibility Study	Feasibility Study	Remedial Action	Draft ROD
ROD		1998	1996	1995	1994	2006	1997	1995	2005	Sept. 2011	Oct. 2014	July 2013	2005	Feb. 2011
Source		Fire training areas	Chemical disposal pit	Sodium hydroxide tank ————————————————————————————————————	Landfill 1 (used for dump and burn wastes) Waste solvents and degreasers	Tooele Army Rail Shop (TARS) Industrial chemicals Waste solvents and degreasers	No record, but potentially waste solvents, leaky underground storage tanks, or former dry cleaning operations	Bldg 225 chromlum spill	Aircraft maintenance facilities Storm water retention ponds Storage tanks Refueling yehicle maintenance facility	Waste solvents and degreasers	Waste solvents and degreasers	Leaked underground diesel and gasoline tanks Waste solvents and degreasers	Waste solvents and degreasers	Electrical transformers storage area
	up Actions/ ent Systems	Source containment system Landfill caps	Groundwater containment wall Source recovery system Interceptor trench Soil vapor extraction system Groundwater collection system	2 asphalt caps	Horizontal drain collection system Soil cap	Groundwater extraction trench Aeration curtain	On-base groundwater extraction system Off-base groundwater extraction system Carbon filtration system (inactive)	Monitored natural attenuation	1,2-DCA extraction system Base boundary groundwater containment system	Soil removal Soil cover	Phyto- remediation treatability study	Soil vapor extraction system	Permeable reactive barrier Base boundary Groundwater containment system Soil excavation	Soil excavation
Status		Cleanup ongoing. Plume shrinking.	Cleanup ongoing. Plume shrinking.	3 of original 5 sites successfully closed.	Cleanup ongoing. Plume stable.	One plume shrinking, other expanding. Cleanup ongoing.	Cleanup ongoing.	Monitoring ongoing.	Cleanup ongoing, Plume stable.	1100 Area plume shrinking. Five sites successfully closed.	Analyzing site conditions. Plume predicted to be stable.	MTBE expanding, BTEXN shrinking.	Cleanup ongoing.	Cleanup in progress. Immediate excavation complete.


### General investigation strategies



# **Charateristics of Vapor Intrusion at Hill AFB**

- Hydrogeology
- · VOC concentrations in groundwater
- Residential areas over and adjacent to groundwater plumes
- Military Installation... surrounded by houses
- Residential homes with and without basements ~ 50%


VOC Concentrations in Groundwater



Vapor Intrusion Program ApproachSample indoor air – Determine if exposure is occurring

- - 24-Hour samples analyzed to EPA Method TO 15
  - Project-dedicated, batch-certified clean Summa® canisters
  - Chemical inventory and inspection prior to sampling
- Advantages
  - Measure exposure concentration
  - Public relations
- Disadvantages
  - Doesn't distinguish vapor source

#### Air Sampling Focus Areas




#### **Project Approach**

- Indoor Air Sampling offered annually
  - Sample during cold months
  - Area-specific COC list
    - Only look for COCs in air that are present in nearby groundwater
  - 24-hr samples
- · Established Action Levels
  - Agreed with EPA/State of UT

	Mitigation Action			
	Level			
Compound	(μg/m³)	(ppbv)		
Carbon Tetrachloride	1.6	0.26		
1,1-Dichloroethane	15	3.8		
1,2-Dichloroethane	0.94	0.23		
1,1-Dichloroethene	209	53		
cis-1,2-	63	16		
Dichloroethene				
trans-1,2-	63	16		
Dichloroethene				
Tetrachloroethene	4.1	0.61		
Trichloroethene	12	2.3		
Vinyl Chloride	2.8	1.1		

CR= 1x10-5 or HI = 1


#### Simplified Decision Logic



Update

#### Hill Program Results


- Since January 2001:
  - 1820 of 2900 homes have agreed to sampling
  - >7500 samples collected
  - TCE detections in 290 (16%) of homes sampled
  - TCE detected above action level in 123 homes
    - 35 of these known or suspected indoor sources
  - 106 Sub Slab Depressurization (SSD) systems installed



Indoor Air 2010 Summary

- -2,710 letters sent
  - 633 agreed to sampling
  - 630 homes sampled
  - 77 homes had detection
    - 12 above action level (All interior sources\*)
      - » 9 -Tetrachloroethene (PCE)
      - » 1 -Trichloroethene (TCE)
      - » 1 -Carbon Tetrachloride (CTCL)
      - » 1 -trans-Dichloroethene (tDCE)
    - Interior sources found in all above except one PCE home that did not agree to source investigation


#### **MITIGATION**




This shows suction point close to basement wall. Note that we always try to put these in the center of the home where possible – some do end up against the wall, but it's not typical


Mitigation

- Sub-slab depressurization systems
  - Have been effective when VI is source of vapors
  - Air Force pays for power/ maintenance and performance monitoring
  - Annual inspection
  - In many cases, will not be effective when an indoor source is present
    - But, we have seen cases where they do pull significant indoor air



### Mitigation Efficiency






#### **Typical Mitigation Costs**

• \$5,000 - \$10,000 Simple SSD


• \$30,000 Complex Case


Advantages
Successful track rate
Application

Mitigation Results



#### Mitigation and indoor sources





- TCE detection frequency and concentration decrease post-mitigation
- In same homes, 1,2-DCA detection frequency and concentration increase post mitigation

Challenges and Optimization

- Interior sources
  - 1,2-DCA case study
  - Portable GC/MS
- Temporal variability

**Community Involvement** 

- Strong community outreach helps inform and prepare public
- Access issues
- Health & Safety Concerns
- Claims Process/Property Values

Hill Program Review

- Summary
  - Apparent vapor intrusion into homes
  - VRS have been effective at reducing concentration below MALs
- · Indoor sampling first approach
  - Overall positive reaction by residents
    - Reaction if we'd chosen another approach?
  - Indoor source problems
    - · Potential over-estimate of VI impacts
    - Concern/frustration for residents

# Decision Logic for New and Existing VRSs


- Minimize unnecessary VRSs
- Multiple-lines-of-evidence

**Exit Strategy Recommendations** 

- · Align areas with the risk of VI
- Install a comprehensive monitoring network and develop water-table concentration maps for each OU
- Use groundwater modeling and CSM to predict when the COC concentrations no longer pose a VI risk.

#### 1,2-DCA Case Study


- No known products (indoor sources) with 1,2-DCA
- TCE & 1,2-DCA in groundwater
- Both 1,2-DCA and TCE on indoor COC list in entire area




30

### 1,2-DCA study (cont'd)

- Few detections early in program
- VR systems did not reduce concentrations
  - Suspected indoor source
  - Detections outside of 1,2DCA plume



■ Try to find a non-groundwater source





#### 1,2-DCA study (cont'd)


- Initial indoor source study identified 1,2-DCA in a molded plastic decoration
  - Confirmed with laboratory emission rate testing (Doucette et al., 2010)
- Portable GC/MS molded plastics are a significant source
  - Molded plastic decorations emitting 1,2-DCA have been identified in many (>20) homes.





#### 1,2-DCA study

- Data review other 'lines of evidence' VI is not the source
  - Detection frequency (over plume vs. not)
  - 1,2-DCA attenuation factors 10 to 100X those of TCE
  - Simplified modeling (J&E)



■ EPA/UDEQ concurrence to remove 1,2-DCA from COC list

Portable GC/MS


- Instrumentation
- Approach
- Examples

\_

#### Instrumentation

- Inficon HAPSITE® GC/MS
- Key features:
  - Custom Methods
    - (~6 min) sample turn time
  - "Clean" chromatograms
    - Target VOCs in SIM mode
  - "Positive" identification
    - Full scan using NIST library
  - Low quantitation limits
    - Chlorinated aliphatics in ppt





#### **Investigation Approach**

Follow the data...

- · Area-by-area sampling
  - Basement, main level, garage
- Focused sampling in high concentration area
  - Room-by-room sampling
  - Container survey/sampling
  - Individual product survey, sampling, and emission rates






#### **Confirming Interior Source**

- · Emission rate measurement
- Purpose: determine if consumer products are a primary source of target VOC

$$E = \frac{C}{V_t * t} \qquad C_{air} = \frac{E}{IV}$$




Product	Emission Rate (μg/min)	Calculated Indoor <sup>(1)</sup> (µg/m³)	Risk Based Conc. <sup>(2)</sup> (μg/m³)	
Hobby adhesives (PCE)	12	3.0	0.41	
Degreaser (TCE)	7	1.7	1.2	
Toilet Cleaner (CT)	0.03	0.008	0.41	


Box model assuming 2500 ft² home, 10 air exchanges/day EPA Regional Screening Levels, May 2010 (10°6)

## Interior Source Example


#### ■ Area by Area Results (ppb<sub>v</sub>)



## Interior Source Example




# Interior Source Example



## Confirming VI

- Entry point sampling
  - Can be isolated
  - Best if done after interior source is ruled out
  - Best done in combination with building pressure control








**Investigation Results** 

- HAPSITE
  - 45 Total investigations
  - -41 Homes = Interior sources
  - 2 Homes = VI related
  - -2 "ND" on day of investigation
- Total Homes with Interior Sources to date = 233
  - 63 unique products containing TCE
  - 95 unique products containing PCE
    - See Dettenmaier and Gorder, 2010 for details

#### **Temporal Variability**


- Two observed behaviors in homes likely to have VI
  - Steady Type High detection frequency and low variability
    - High probability that one sample will:
      - » indicate if VI is occurring
      - » be good indicator of exposure concentration
  - Variable Type Low detection frequency and high variability
    - Low probability that one sample sufficient to indicate occurrence of VI

Steady Type VI



#### 

# Variable Type VI



# Managing Temporal Variability


- · Variable Type VI poses a number of problems
  - Access Expense/time of multiple samples
  - False positive/false negative results
  - Uncertainty for building occupants
- Sampling while controlling building pressure (P) is a way to manage temporal variability

#### **Building Pressure Control**


- Development for VI led by Tom McHugh (GSI) See references
  - Induce positive or negative building P during investigation
  - To confirm VI, negative building P is most useful in turning VI on
  - Induced negative P provides a "worse than normal" case




# VI & Pressure Control Example




## Pressure Control Example




#### **Conceptual Investigation Strategy**




Sewer VI Summary



# Sewer VI Summary



\_



**Key Points** 

- Hill AFB chose to sample inside air for VI characterization
- · VI is determined in some homes
- · Indoor sources are very problematic
  - Some progress identifying sources
  - Looking toward more "top down" investigation
- Public reaction has been generally favorable
- · Would choose indoor sampling approach again
  - Plan on 'top-down' characterization
  - Add better water-table characterization
  - Consider pre-screening for indoor sources

Acknowledgement: Jarrod Case, Hill AFB Kyle Gorder, Hill AFB Eric Dettenmaier, Hill AFB



#### References

- Doucette, W.J.; Hall, A.J.; Gorder, K.A. Emissions of 1,2-dichloroethane from holiday decorations as a source of indoor air contamination. *Ground Water Monitoring and Remediation* 2010, 30 (1), 64-71.
- McHugh, T.; Gorder, K. Methods to distinguish between vapor intrusion and indoor sources of VOCs at residences near Hill AFB, Utah, USA. In Vapor Emission to Outdoor Air and Enclosed Spaces for Human Health Risk Assessment: Site Characterization, Monitoring, and Modeling; Saponaro, S., Sezenna, E., Bonomo, L., Eds.; Nova Science Publishers, Inc.: Hauppauge, NY 2010
- Dettenmaier, E., and K.A. Gorder. Detailed Indoor Air Characterization and Interior Source Identification by Portable GC/MS. Presented to the Air and Waste Management Association Vapor Intrusion Specialty Conference, Chicago, IL. September 30, 2010. <a href="http://events.awma.org/education/Presentations/Session">http://events.awma.org/education/Presentations/Session</a>
   %208/3\_AF\_AWMA\_IA\_09272010\_EMD.pdf (accessed Feb 24, 2011)

#### Questions

Resources & Feedback

- To view a complete list of resources for this seminar, please visit the <u>Additional Resources</u>
- Please complete the <u>Feedback Form</u> to help ensure events like this are offered in the future

